

Model: Portege G710

- 1 - Power on phone with sim accepted
- 2 - Put pin code
- 3 - When phone is ready, go to: START - ACCESORIES - UNLOCK SIM
- 4 - Enter UNLOCK CODE, and ACCEPT